

Installation Procedure for Dynics UPS6000

1. If you have Solidcore enabled please disable solidcore (If you do not have solidcore installed skip step 1 and step 5)
2. Remove the pre-existing UPS software if upgrading from a UPS3500 to UPS6000.
3. Installing the UPS USB driver.
 - a. Connect the UPS USB to the PC.
 - b. Go to the folder "CP210x_Universal_Windows_Driver"
 - a. For 64-bit OS versions – install "CP210xVCPInstaller_x64.exe".
 - b. For 32-bit OS versions – install "CP210xVCPInstaller_x86.exe".
4. Installing the Dynics UPS Application
 - a. Install the setup file "DynicsUPSGUIsetup.msi".
 - b. This setup wizard will take you through a series of steps, click next on all the steps and the installation will start.
4. Installing the Dynics UPS Windows Service
 - a. Install the setup file "DynicsUPSThread_Setup.msi".
 - b. This setup wizard will take you through a series of steps, click next on all the steps and the installation will start.
 - a. Once the installation is complete you may restart the PC.
5. If you have Solidcore installed please run this command "sadmin so" to re-solidify before you enable Solidcore.